

Item No. 1020BK INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

ASSEMBLY AND INSTALLATION

1. Remove the pre-assembled waterproof gaskets (6) and screws (5) from the mounting unit (2). 2. Attach the mounting unit (2) to the outlet box (not included) with the mounting screws (3), with the sides of the mounting unit (2) facing away from the outlet box (1).

3. Pull out the outlet wire and ground wire from the outlet box (1). Make wire connections:

- -Connect White wire from fixture (7) to White wire from power source with wire nut (4).
- -Connect Black from fixture (7) to Black wire from power source with wire nut (4).
- -Connect Copper wire from fixture (7) to ground wire from power source with wire nut (4).
- 4. After wires are connected, tuck them carefully inside the outlet box (1).

5. Secure the light fixture (7) to the outlet box (1) by aligning the holes of the back plate on light fixture (7) with the previously-removed waterproof gaskets (6) and screws (5).

6. Place the glass shade (8) to the socket of light fixture (7), and secure them together with socket ring (9).

7. Install bulb (not included) to the socket. Do not exceed the maximum capacity recommended on the socket.

CAUTION: To avoid any waterproofing problems, make sure the light fixture fits the mounting surface perfectly during installation and use waterproof glue (not included) around the canopy for better sealing after installation.

INSTALLATION IS NOW COMPLETED

